

ZENER 8000

SW08024

Application Guide

PID Irrigator Control

Important Warnings:

- ALL PROTECTION PROVIDED BY THE ZENER 8000 IS FOR OPERATIONAL PURPOSES ONLY. SEPARATE INDEPENDENT METHODS MUST BE EMPLOYED TO PREVENT ECONOMIC LOSS.
- THIS EQUIPMENT CONTAINS HIGH VOLTAGE AND REMAINS CHARGED FOR A PERIOD AFTER POWER IS REMOVED. ALWAYS ALLOW 15 MINUTES FOR COMPLETE DISCHARGE AND CHECK FOR THE PRESENCE OF AC OR DC VOLTAGE BEFORE ACCESSING MOTOR PHASE TERMINALS, WIRING OR INTERNAL COMPONENTS.

Check List: What information you need to know

1. What is the motor nameplate Full Load Current ? _____ Amps
2. What is the motor nameplate RPM ? _____ rpm
3. What is the desired operating pressure (in psi) ? _____ psi
4. What is the maximum system pressure allowable (in psi) ? _____ psi
5. What is the transducer's pressure rating (ie. @ 20mA) ? _____ psi
6. What is the minimum operating speed of the pump (= X% of 50Hz) ? _____ Hz



Product Support
www.zener.com.au/support-8r.php



Reference Manual
www.zener.com.au/images/im00140.pdf



PID Irrigator Application Guide (this document)
www.zener.com.au/images/im00160.pdf

Commissioning Overview

Each step must be completed in order shown before proceeding to the next. Before proceeding to power the ZENER 8000 and operating the pump, check all wiring is correct and that the pump and plumbing system is in a state fit for operation. If any parameters are changed it is important to 'save changes' when prompted exiting the menu.

Preparation:

| | | |
|-----------|---|--|
| 1. | Read all safety instructions & warnings | <i>Refer to the installation manual</i> |
| 2. | Install as per instruction manual and this 'Application' guide | <i>Refer to the installation manual and Page 4 of this guide</i> |
| 3. | Read this application guide carefully and ensure it meets your requirements | Go to page 3 |
| 4. | Familiarise yourself with operating the ZENER 8000 and application menus | <i>Go to page 5 to 11</i> |

Preliminary Checks:

| | | |
|-----------|--|----------------------|
| 5. | Load the application & adjust initial parameters | <i>Go to Page 7</i> |
| 6. | Operate in local mode to check direction | <i>Go to Page 11</i> |
| 7. | Check pressure transducer feedback | <i>Go to Page 11</i> |

Operational Check & Fine Tuning:

| | | |
|------------|---|----------------------|
| 8. | Operate in remote mode and check PID. Calibrate PID if required | <i>Go to Page 12</i> |
| 10. | Check & calibrate 'PIPE FILL' if required | <i>Go to Page 14</i> |
| 11. | Check overall operation and protection | |
| 12. | Save 'Custom Defaults' and/or record settings | |

Application Overview

| | |
|---------------------------|-------------------------------------|
| Part Number: | SW08024 |
| App Group: | Standard |
| Description: | PID Irrigator Control |
| Menu Text: | PID Irrigator |
| Compatibility: | ZENER 8000 Firmware 5.2.13 or later |
| Application Guide: | IM00160 |



What is a ZENER 'Application'?

An 'Application' is firmware that aims to simplify wiring, programming and the commissioning of ZENER 8000. An 'Application' programs the drive and creates new user friendly menus with the essential settings. This eliminates timely setups, the reading & interpretation of complex manuals and ensures all critical protection is installed & set up correctly. There is generally no reason to program additional parameters unless there is a variation to the intended operation of this 'Application'.

PID Irrigator Application Summary:

This application provides an advanced PID Pressure Control System using an external pressure transducer. The ZENER 8000 will maintain a constant pressure with changing water consumption requirements.


1 of 4 user configured set points provides the pressure for the system to maintain. As the pressure changes the ZENER 8000 automatically adjusts the speed to ensure constant pressure is maintained.

When demand decreases the drive will reduce speed to reduce pressure accordingly. As the flow & speed reduce the load (current) also reduces. If the installed flow switch detects "no-flow", the ZENER 8000 will stop pumping and await reset.

A 'Pipe Fill' feature is available to run at a set speed during filling then automatically changeover to PID mode when the set pressure is reached.

ZENER 8000 protection for the pump & motor:

- i. Motor Overload protection
- ii. Output Short Circuit protection
- iii. Loss of transducer signal
- iv. High Pressure Pulse Protection
- v. Pressure Out of Regulation Protection
- vi. Optional Low Bore level protection
- vii. Optional No Flow protection




System Requirements:

1. ZENER 8000 with the Application: "PID Irrigator" fitted with an extended features board (AF08001).
2. A pressure transducer and a pressure gauge (for calibration purposes) located between the pump and any discharge valves.
3. A 4-20mA pressure transducer. However different devices can be used by varying the appropriate parameters.
4. Non return valves may be located as determined by the application. Their location does not affect pressure regulation.
5. The motor & pump are in good working order.
6. The "HI PRESSURE" trip and "PRESSURE ERR" trip are for operational purposes only. Separate and independent methods must be employed to prevent economic loss. A pressure relief valve is recommended.
7. Optional control input available for 'Bore level'. External level sensing device required.
8. Optional control input available for 'Flow Switch'. Closed contact indicates flow.

Control Wiring:

Note: All control wiring should be screened.




Ensure the ZENER 8000 is in local mode (remove link in terminal 5) to prevent operation while programming and performing preliminary checks.

NOTES:

1. If the optional 'Flow switch' is not installed, a bridging link must be fitted. i.e. +5V → D3(35)
2. If the optional 'Low Bore Level' switch is not installed, a bridging link must be fitted. i.e. +5V → D4(37)
3. The set up supports several run wiring methods. As shown in the diagram above these include: "START/STOP" with pushbuttons, "RUN/Stop" and "Power Up /Start Up".

Operation Displays

The operational displays show the operating state of the ZENER 8000. The operational displays include: Speed / Reference Display, Meter Display, PID Display, PID / Meter Display and kWhr / Hours Run Display. Press **ENTER** (ENTER) to step through each display.



Speed / Reference Display

The top line displays the operating output frequency and the second line displays the speed reference and the drive status

Meter Display

The top line displays the operating output frequency and power and the second line displays motor load and output current.

PID Display

The top line displays the process variable (PV) with its units and the second line displays set-point variable (SV) expressed with the same units.

PID / Meter Display

The top line displays the operating output frequency and process variable (PV) and the second line displays output current and motor speed.


kWhr / Hours Run Display

The top line displays the kWhrs consumed by the motor and the second line displays accumulated running time of the motor

Display Messages

| Message | Meaning |
|--|---|
| REM | REMOTE MODE: Start/stop control from digital inputs. |
| LOC | LOCAL MODE: Start/stop control from local console. |
| PID-A ON (OFF) | PID ON (or OFF): PID controller is operating or not. |
| FWD or REV | Forward or Reverse direction selected from local console or Digital inputs or internal |
| PV-A OOR | 'Out of Regulation': A warning that PID is operating and the PV is not equal to the SV. |
| -DRY- | Bore level switch is indicating a low bore and/or in the timeout period before |
| Filling | Pipe Fill Mode is active. When set pressure is reached will switch to PID mode. |
| Fill T/out | Warning: The fill time has lapsed and pressure has not reach required level |
| <ul style="list-style-type: none"> Refer to the installation manual for a full list of warnings | |

Loading an Application:




Loading an Application will program the drive for you and create a unique menu with the parameters you need to adjust.

If 'APPLICATION <NONE>' is displayed this means there is no Application loaded.

If 'APP: PID Irrigator' is displayed this means this an application has been loaded. The application will be displayed.

To remove an unwanted application, see the section "Removing an Application" below.


To load the application:



This should be performed in LOCAL MODE as the pump may run. (Remove link in terminal 5)

Removing an Application:

Factory defaults must be restored to prepare the ZENER 8000 for application loading. To restore defaults follow the procedure below.



NOTE:
To restore defaults the ZENER 8000 must not be in REMOTE mode. Remove terminal 5.

Press ESC and ENTER to SAVE CHANGES when prompted. Power Down the ZENER 8000 completely and then REPEAT the procedure to load the application.

Application 'CONFIG' & 'USER' Menu:


There are now 2 additional menus with this application, a 'CONFIG MENU' and a 'USER MENU'.

CONFIG MENU

The 'CONFIG MENU' is created for initial setup. This can be found in the A00 DEFAULT Menu and has all the parameters required. General access to this menu can be locked out.

USER MENU

The 'USER MENU' is created for the operator. In this application it provides access to the 'Set pressure' only. Access to other settings can be locked out.




Always remember to press 'ENTER' when prompted to save changes.

Do not remove power while saving!!

CONFIG MENU Parameters:

After loading the application the CONFIG MENU will appear. Modify the following parameters. If the CONFIG menu does not appear read page 8.




Ensure the ZENER 8000 is in local mode (remove terminal 5) to prevent unexpected operation.

Initial parameters to adjust:

| | <u>Parameter</u> | <u>Default</u> | <u>Explanation</u> |
|-----|------------------|----------------|--|
| 1. | Rated Motor Amps | ?? Amps. | Enter Motor nameplate full load current. |
| 2. | Overload Current | ?? Amps. | Enter Motor nameplate full load current. |
| 3. | Rated Motor rpm | 1470 rpm | Enter Motor nameplate speed in rpm. |
| 4. | Transducer units | “psi” | Select the desired pressure units. |
| 5. | Transducer Scale | 200.0 | Enter the rating of the pressure transducer at 20mA, in psi |
| 6. | Pressure Ref 1 | 100 psi | Enter the desired operating pressure when this reference is selected. |
| 7. | Pressure Ref 2 | 100 psi | Enter the desired operating pressure when this reference is selected. |
| 8. | Pressure Ref 3 | 100 psi | Enter the desired operating pressure when this reference is selected. |
| 9. | Pressure Ref 4 | 100 psi | Enter the desired operating pressure when this reference is selected. |
| 10. | Pressure Tol. | 25% | Enter the tolerance of pressure from the reference as a percentage of the transducer pressure scale |
| 11. | Pressure Q time | 30 sec | Enter the out of tolerance time to register “PRESSURE ERR” |
| 12. | Low Bore timeout | 0 sec | Leave at 0 sec for the moment. <ul style="list-style-type: none"> This feature requires an external bore level switch. Link terminal 1 to Terminal D4(37) if no bore level switch installed. Enter the time to restart after the ‘Low Bore’ switch-contact returns to the closed position. “-DRY-” is displayed during the timeout period. |

| | Parameter | Default | Explanation |
|-----|----------------------|----------------|--|
| 13. | No Flow Q time | 20 sec | Enter the out of tolerance time to register “No Flow” This feature requires an external no flow switch. Link terminal 1 to Terminal D3(35) if a flow switch is not installed. |
| 14. | High Trip Level | 180 psi | Adjust if required .Adjust level for ‘high pressure’ trip (in psi). The trip time (default 0 seconds) can be adjusted in another menu if required (Refer to User Alarm 4). |
| 15. | MIN Speed (Hz) | 0 Hz | Leave at 0Hz (or minimum pump speed) to check pump rotation. This should be at least the minimum operating speed for the pump. Eg. 30Hz. When started, the pump will run to this speed. |
| 16. | Pipe Fill | OFF | Leave OFF for the moment. Pipe fill mode runs the pump at a fixed speed until the pipes fill and the pressure begins to build. When the ‘Fill to Level’ pressure is reached it automatically switches to PID mode. Select ‘PV Threshold’ for pipe fill based on pressure. |
| 17. | Pipe Fill Speed (Hz) | 40 Hz | Leave for the moment. This is the operating speed for pipe fill mode |
| 18. | Fill to Pressure | 80.0 psi | Leave for the moment. This is the pressure level to change from Pipe Fill to PID mode |
| 19. | Fill Time | 40 sec | Leave for the moment. This is the time period for the pipe fill to reach pressure. |

When back to the beginning (first parameter ‘Rated Motor Amps’), press ESC until:




Preliminary Checks

The following should be performed with the ZENER 8000 in local mode to provide better control to carry out the checks. Ensure the **motor, pump and plumbing is ready and safe** to operate.

To operate in local mode:

Remove the link in terminal 5, this selects local mode.



REM= REMOTE OR PID MODE [Control using terminal inputs]

LOC = LOCAL MODE [Control using push buttons]

Top display: Actual Speed in Hz (50Hz = full speed)

Bottom Display: Set speed

Press **FWD/▲** to start

Press **FWD/▲** to increase the speed

Press **STOP** to stop the pump

Note: If there is a minimum speed set it will go straight to that speed. To increase above this speed you will need to hold down the UP button until it goes above the minimum speed setting.

Check motor/pump direction:


Press **FWD/▲** to start and increase the motor speed sufficient to test the direction. The ZENER 8000 will run to the minimum speed. Use the **▲** to increase the speed above the minimum speed level.

If the motor shaft or pump rotates in the wrong direction, remove the input power, wait for the ZENER 8000 to discharge and swap any two motor phase wires. Re-apply input power and recheck direction

Check pressure transducer feedback:

Press **FWD/▲** to start & increase the motor speed until the desired operating pressure is indicated on the pressure gauge. Press **↵** (ENTER) to scroll through the operator displays (see page 5) to the PID display shown below.

- Check that the top display (PV) is displaying the correct pressure as per the pressure gauge. The service menu can be used to display the mA being received from the transducer. If this is not within acceptable tolerance, investigate and rectify.




- Check the motor & pump are adequate and operating correctly.

Checking the PID operation


Ensure the system is ready to pump and discharge valve is open for flow required. **Re-install the wire in terminal 5 to operate in Remote/PID Mode** and apply power to the ZENER 8000.

Find the PID display to monitor the performance:



Check the following:

1. Start the system as intended.
2. The ZENER 8000 operates and stabilises at a speed where the PV = SV.
3. The pressure (i.e. PV) indicated on the ZENER 8000 is correct with reference to the gauge. If not correct turn the pump off and investigate.
4. Check that the control is stable and responds as desired to changes in set point. Refer to PID tuning guide if unstable. These parameters are found in the following menu:



5. Check pressure regulation with all combinations of equipment connected to the discharge port.
6. Check to see that pressure is maintained and the system responds acceptably. Refer to tuning guide if response is slow or over shooting occurs.

PID Tuning Guide

The Proportional gain: amplifies the difference between the set point reference and feedback signals. The **H01 Prop. Band** value is the proportion of input required to generate 100% at the output of the PID control. For example **H01 Prop. Band** is 200.0%, the proportional gain is $100/200 = 0.5$. That is 2 units of input will generate 1 unit of output. The higher the % value, the lower the 'proportional gain'.

The integral time: The integral action adds a corrective component to reduce a constant error difference between set point and feedback signals. The greater the error, the quicker the gain increases. The **H02 Integ. time** value sets the time to 'repeat' the error difference between set point and feedback signals - This assumes the Proportional gain is equal to 1.

A low **H02 Integ. time** value attempts to regulate the process variable quickly. However if excessively low, over shooting and under shooting will be more prominent.

A high **H02 Integ. time** value diminishes over shooting and under shooting. However regulation takes longer to achieve.

Guide to PID Tuning:



The guide below assumes short ramp times. Long ramp times will dominate system performance and the steps below will have little or no effect.

| Step | Problem | Action |
|------|--|---|
| 1. | The plumbing is set for typical flow but the system responds too slowly | 1.1 Stop the ZENER 8000 & pump 1.2 Halve the value of H01 Proportional band . Avoid adjustments below 10%. 1.3 If H01 Proportional band is below 10% proceed to step2. 1.4 Stop & restart the ZENER 8000 & pump. 1.5 Observe the time it takes to reach pressure (or reacts to changes) 1.6 Repeat from step 1.2 if the response is slow. Otherwise proceed to step 2. |
| 2. | The system starts to overshoot or oscillate | 2.1 Stop the ZENER 8000 2.2 Double the value H01 Proportional band 2.3 Start the ZENER 8000 and observe the time it takes to reach pressure or reacts to changes 2.4 Repeat from step 2.1 if the system still overshoots or oscillates. Otherwise proceed to step 3. |
| 3. | The system still responds slowly (after adjusting H01 Proportional band) | 3.1 Halve the H02 Integral Time 3.2 Observe the time it takes to reach the pressure (or reacts to changes) 3.3 Repeat from step 3.1 if the response is still slow. Otherwise proceed to step 4 |
| 4. | The system starts to overshoot or oscillate (after initial adjustments to H02 Integral Time) | 4.1 Double the H02 Integral Time 4.2 Observe the time it takes to reach the pressure (or reacts to changes) 4.3 Repeat from step 4.1 if the system still overshoots or oscillates 4.4 If the response is acceptable then you may stop tuning |

Remaining Parameters:

The remaining parameters to implement & adjust if required are:

Pipe Fill:

The pipe fill option allows the ZENER 8000 to operate at a reduced speed to fill the pipes on start. Pipe fill is only activated when a start/run command is first given.

| | | |
|----------------------|----------|--|
| Pipe Fill | DISABLED | To Enable, set to 'PV Threshold' . This will provide an automatic changeover to PID when a pressure level is reached. |
| Pipe Fill Speed (Hz) | 40 | Adjust the speed to operate during pipe fill mode |
| Pipe Fill Level | 80 psi | Adjust the level to switch from 'Pipe Fill Mode' to 'PID mode' |
| Pipe Fill time (s) | 40 | Adjust to the time required to reach the 'Pipe Fill Level' pressure. |

Bore Level Timeout:

| | | |
|------------------|---|---|
| Low Bore timeout | 0 | Enter a time period to restart after a 'Low Bore' is detected or install link if a 'Bore level switch' is not installed. This feature requires a bore level switch to be installed. When an 'open contact' is present on input D4(terminal 37) the ZENER 8000 stops and displays the warning '-DRY-'. When the contact closes there is a delay before the pump restarts. |
|------------------|---|---|

Note:

1. If no 'Bore Level switch' is installed fit a bridging link between terminal 1 and 37.
2. If operated with a start/stop switch the low bore switch will stop the pump and not allow a restart until the time-out period has lapsed.

Variations & Other Adjustments:

Other parameters may need to be adjusted because:

- The setup may vary from the intended application Eg. Use different set point source/reference such as a potentiometer.
- Additional requirements which the application does not include. Eg. An additional alarm for over current.

Parameters that you may want adjustment include:

Change Ramp Times:

Ramp types: C030 Accel Time & C031 Decel time = ramp time above minimum speed
C032 S-time = ramp time to minimum speed

ESC to Menu > <DOWN>>> **C00 PERFORMANCE** <ENTER><DOWN>>>**C03 RAMP**<ENTER to edit><UP/DOWN to select ramp type>>and<ENTER to save><ESC> ('ramp time' is time taken from 0 to 50Hz)

Note: The time entered is the time from 0 – B03 MOTOR Hz.

Thermistor Input:

Allows a thermistor input for motor protection into terminals 40 and 42 on the option board. This function needs to be enabled if required.

ESC to Menu <DOWN>>> **G00 INPUT/OUTPUT** <ENTER><DOWN>>>**G09 Thermistor**<ENTER to edit><<UP/DOWN to select enable>>and<ENTER to save><ESC>

Set point Variable:

The set point in this application is a preset value. It is possible to alter this to another source such as;

- Potentiometer
- Multiple speed
- Analogue reference signal (0-5V, 0-10V, 4-20mA)
- Or other

ESC to Menu <DOWN>>> **H00 PID PARAMETER** <ENTER>**PID-A Controller**<ENTER><DOWN>>>**H06 SV Choice**<ENTER to edit><<UP/DOWN>> and <ENTER to save><ESC>

Potentiometer:

To select Analogue input for SV Choice:

ESC to Menu <DOWN>>> **H00 PID PARAMETER** <ENTER>**PID-A Controller**<ENTER><DOWN>>>**H06 SV Choice**<ENTER to edit><<Select AI(10,11)>> and <ENTER to save><ESC>

To configure Potentiometer input for 0-5Vdc:

ESC to Menu <DOWN>>> **G00 INPUT/OUTPUT** <ENTER> <DOWN>>>**Analogue Inputs**<ENTER to edit><<Select AI(10,11)>><ENTER><Select 0-5V><ENTER>. <ESC>

Others:

For other Set point variable sources refer to the reference manual for details on connection, wiring and the input parameters required.

Max Hz:

To reduce or increase the maximum speed output.

ESC to Menu <DOWN>>> **C00 PERFORMANCE** <ENTER><DOWN>>>**C02 MAX Hz**<ENTER to edit><<UP/DOWN>>and<ENTER to save><ESC>

Motor Volts & Hz:

Adjust the output voltage and frequency as per motor nameplate information.

ESC to Menu <DOWN>>> **B00 MOTOR** <ENTER><DOWN>>>**B01 MOTOR VOLTS** <ENTER to edit><<UP/DOWN>>and<ENTER to save><ESC>

ESC to Menu <DOWN>>> **B00 MOTOR** <ENTER><DOWN>>>**B03 MOTOR HZ** <ENTER to edit><<UP/DOWN>>and<ENTER to save><ESC>

Adjust Transducer feedback Zero/Span:

If there is a slight error in the PV reading it may be necessary to make minor adjustment to the input signal for the transducer feedback. Adjust the 'Ref @ MIN in' and/or 'Ref @ MAX in'.

- *ESC to Menu* <DOWN>>> **G00 INPUT/OUTPUT** <ENTER> <DOWN>>>**Analogue Inputs**<ENTER to edit><<Select AI(32,34)>><ENTER><DOWN>>>**G103 ref @ MIN in**<ENTER><UP/DOWN to adjust><ENTER to save><ESC>
- <DOWN>>>**G104 ref @ MAX in**<ENTER><UP/DOWN to adjust><ENTER to save><ESC>

Parameters programmed by the Application:

The following parameters are automatically programmed by the 'Application' when it is loaded. They are listed below for reference purposes only.

Application Menu:

- | | |
|--|--|
| 1. "Rated motor amps" B02= ? | // Pressure Error Trip config G230= 2 //UA1 active in PID closed loop |
| 2. "Overload current" D020= ? | G231= 101 //UA1 signal: "PV-A OutOfReg" |
| 3. "Motor RPM" B04= ? | G232= 0 //no delay G233= "UA1:PRESSURE ERR" |
| 4. "Transducer units" = "psi" H08= 1 | // Sigant lost Trip G106= 2.0 //AI(32,34) cmp lo thresh = 2.0mA |
| 5. "Transducer scale" = 200psi H09= 200.0 | G240= 1 //UA2 trip active with RUN cmd G241= 64 //UA2 signal: Lo AI(32,34) |
| 6. "Pressure Ref 1" = 100psi F100= 50.0 | G243= "UA2: SIGNAL LOST" |
| 7. "Pressure Ref 2" = 100psi F100= 50.0 | // No Flow Trip config G250= 1 //Run command |
| 8. "Pressure Ref 3" = 100psi F100= 50.0 | G251= 31 //UA3 signal: ~D3(35) G253= "UA3: NO FLOW " |
| 9. "Pressure Ref 4" = 100psi F100= 50.0 | // High Pressure Trip config G260= 0 //UA1 trip always active |
| 10. "Pressure Tol." = 25% H131= 250 | G261= 72 //UA1 signal: PV-A OVER G262= 0 // No time delay on this trip |
| 11. "Pressure Q time" = 30sec H132= 30 | G263= "UA4: HI PRESSURE" |
| 12. "Low Bore Timeout" = 0sec G070= 0 | // Low Bore config G271=55 //~TMR1 |
| 13. "No flow Q time" = 20sec G252= 20 | G272=" -DRY- " G01=7 //Custom |
| 14. "Hi Pressure Lvl" = 180psi H111=180.0 | I02=95 //Logic Block 1 I201=10 //D2(3) |
| 15. "Minimum Speed " = 0Hz C01= 0 | I202=54 //TMR1 I203=17 // LB1 logic |
| 16. "Pipe Fill" = DISABLED H120= 0 | G071=2 //TMR1 mode: Delay ON Init G0720=0 //TMR1 IN2=ON |
| 17. "Fill Speed(Hz)" = 40Hz H123=40 | G0721=34 //TMR1 IN1=D4(37) |
| 18. "Fill to Level" = 80psi H122=80.0 | // PID config H01= 200.0,"Prop. band value" |
| 19. "Fill Time(s)" = 40sec H121=40 | H02= 2.00,"Integrator time" H06= 15 //PID-A SV: REF SEL H07= 1 //PID-A PV: AI(32,34) H102= 1 //Resume: by PV threshold J02 = 2 //display: PID disp |

Other Preset Parameters

C030= 3.0 //1 sec Accel
 C031= 3.0 //1 sec Decel
 C032= 1 //1sec Accel & Decel to Min Hz
 C033= 1 // Dual ramp
 F010= 2 //Remote ref: PID-A Opt
 F061= 7 //USER REF1: PRESET1
 F062= 8 //USER REF2: PRESET2
 F0631=22 //Selector 1: D2(33)
 F0630=26 //Selector 2: D1(31)
 F1001=1 //PRESET1..4 units: PID-A
 F1011=1
 F1021=1
 F1031=1
 G108= 2 //AI(32,34) config: 4 to 20mA

Trouble Shooting Guide:

The following assumes all standard configurations programmed by the Application without any changes.

| Symptom | Checks/Remedy |
|---|---|
| No Application 'PID Irrigator' Menu is present | <ul style="list-style-type: none"> If you have not loaded the 'Application' following the instructions on page 7 If you have loaded the Application and no menu, restore defaults and reload following the instructions on page 7 |
| Pump running wrong direction | <ul style="list-style-type: none"> Swap two motor cables on the ZENER 8000 output or at the motor |
| PV display is 0 when gauge indicates pressure | <ul style="list-style-type: none"> Check the application has been loaded. Refer to page 7 Check transducer scale has been entered and is correct. In the service menu, check analogue input AI(32,34) is reading correct mA If not reading correct mA, check transducer wiring & polarity Measure DC mA in transducer wiring |
| PV reading is not correct | <ul style="list-style-type: none"> Check transducer scale has been entered and is correct. In the service menu, check analogue input AI(32,34) is reading the correct mA Measure & check DC mA in transducer wiring is correct and transducer is operating correctly If only a small error may need to adjust AI(32,34) to read correctly |
| Pump does not start | <ul style="list-style-type: none"> In the service menu, check digital inputs have '1' on terminals 2,3,4,5 & 6. If a start push button is used, check it provides a '1' on terminal 4 when pushed. If not, check input wiring. Is the 'SV' on the display indicating the 'Set pressure' entered in the 'Application Menu'? E.g. 100psi. Is the PV reading the correct pressure (as per pressure gauge) If a trip is displayed investigate & rectify. Will need to reset trip. If pipe fill is enabled, check 'Pipe Fill Speed' entered is not 0Hz. |
| -DRY- is displayed and will not start | <ul style="list-style-type: none"> Bore level is low Check bore level switch operating correctly and connections. If no bore level switch, check bridging link is fitted between terminal 1 and 37. |
| Pressure does not build up to the 'Set Pressure'. | <ul style="list-style-type: none"> Ensure PV display is correct Motor/Pump rotating wrong direction. Check & rectify. If Pipe fill is enabled check 'Fill speed (Hz)' is not too low. Disable Pipe fill and check again If the drive is not running at 50Hz, check motor current in all 3 phases and drive is not indicating 'current limit' If running at 50Hz check pump and plumbing. |
| PID/ pressure control is unstable | <ul style="list-style-type: none"> Ensure Pressure Transducer is operating correctly and the feedback (PV) is stable when the pump is not running and also running in local mode at a fixed speed. Tune the PID using the parameters and guide on page 12 |
| Current limit is displayed | <ul style="list-style-type: none"> Check the motor current and the drive is correctly matched to the motor & pump. Check the current in each motor phase to ensure balanced |
| Continually in Pipe Fill Mode | <ul style="list-style-type: none"> Pipe Fill Speed too low, insufficient flow and pressure not reaching pipe fill level. Problem with pump/motor not increasing pressure to pipe fill level. Check Pump/motor |

More Information or Assistance:

For details on all the features and parameters available refer to the ZENER 8000 Reference Manual available on the ZENER website: www.zener.com.au



ZENER AUSTRALIAN DISTRIBUTORS

New South Wales

Sydney

Zener Varidrive Solutions
366 Horsley Road
Milperra NSW 2214
Phone: 02 9795 3600
Email: sales@zener.net

Regional NSW

Zener Varidrive Solutions
1 William Street
Maryville NSW 2293
Phone: 02 49696788
Email: sales@zener.net

Queensland

Zener Electric Queensland Pty Ltd
Unit 23, 28 Burnside Road
Yatala QLD 4207
Phone: 07 3807 7377
Email: sales@zenerqld.com.au

Western Australia

Power Control Products
Unit 5, 144-146 Bannister Road
Canning Vale WA 6970
Phone: 08 92562133
Email: sales@powercontrol.com.au

South Australia

Rototech Pty Ltd
34-36 Kinkaid Avenue
North Plympton SA 5037
Phone: 1300 553 552
Email: mail@rototech.com.au

Victoria

Rototech Pty Ltd
23 James Street
Clayton South VIC 3169
Phone: 1300 553 552
Email: mail@rototech.com.au

<http://www.zener.net>

©Zener Electric Pty Ltd 2018